

# 10' Monticello Set-Up Instructions

Assemble column sections first

## Monticello Column Set-Up Instructions

U.S. Patent  
#5,439,043

**1**

Magnets on ends

Magnets on ends

Start with the flat, flexible panel...

**2**

Roll the flat flexible panel into a column shape...

**3**

The magnets on the ends “snap” together to make the flexible panel round. Place support clips over the magnetic bars **at top and bottom**, to lock them together.

**4**

Next, the hubs are placed into both ends of the Column to keep it round...

**5**

Now, the bottom column is ready to be **Snapped Magnetically** to the unit...  
NOTE: some columns may **slide onto** the panels with a **U-channel**.

**6**

Next, place the top column piece onto the bottom piece, guiding the **square pins** into the **square channels** to hold it in place and keep the magnet strips (or U channel) aligned.

**1**

Left Outside

Right Outside

Sides swing forward after top section is joined.

9' Booth

**2**

Begin set-up of center section with **Four Panel Base** between and slightly behind columns .

**Insert stacking guides** in all sections of base panel.

With center section “accordion” folded, **lower upper section onto base**. (Shown slightly unfolded in diagram for clarity)

Next, swing sides forward toward columns.

**Push center hinge forward** to make center of display area flat.

**Slide entire center section forward and snap the magnets onto the magnetic strips on the columns or insert the side panels’ edges into “U” channels on columns.**

**Set-up is complete and display is ready for graphics.**

Visit [goExpogo.com](http://goExpogo.com)

**EXPOGO!**  
ExpoStar® Presenta® ArchiForm®

(800)-891-1869