

Attaching Graphics to the MagicPak



1. Turn image with picture side down. Peel back small amount of protective strip on the top bar.



2. Place top bar against upper edge of image. Remove protective strip. Press firmly.



3. Turn image and bar over and burnish down bar to insure good contact with adhesive.



4. Remove white protective strip from leader.



5. Apply image, picture side up. Follow the blue line to properly line up the graphic.



6. Apply tape over the joint on both sides.



7. Grip graphic & unit firmly with left hand (maintain a tight grip). Remove pin with right hand.



8. Maintain a tight grip on graphic and gradually feed into roller mechanism.



9. Continue to maintain a tight grip and feed into the roller mechanism.



10. You're finished. Before packing up the Magicpak, remember to store the pin into the slot on the cannister.

WARNING!

The graphic is under constant tension from the Magicpak spring mechanism. Using an improper adhesive could result in failure of the bond between the profile bar and the graphic, causing the graphic to forcefully retract into the unit.

Flexibility is important!

The image must be flexible enough to retract easily into the cannister. Laminating both sides with a polyester material is not recommended. Using 10 mil polyester or polycarbonate laminate can make the image too rigid to retract.

To interchange graphics:

Extend graphic all the way out of the unit and reinsert the locking pin. Remove the old graphic from bottom leader. The top bar stays with the graphic (You must obtain a new top bar for the new graphic). Repeat steps one through 10.

Visit goExpogo.com

EXPOGO!
ExpoStar·Presenta·ArchiForm

(800)-891-1869