



# RSS 12 Header Soffit Instructions



1. Set up display unit (with 12" gaps between section ends for the joiner curves) as shown in **Set-up instructions**
2. Attach the Hanger bar to the back of the unit with the folding hooks.
3. Assemble Header as shown in header set up instructions, and hang onto display with magnet facing up on bottom cross bar.
4. Lay Soffit panel onto "L" section of the Hanger bar so that magnet snaps onto the Header magnet.